



The pool trolley is a device for lifting and moving pool tables with a total weight **no greater than 600kg**. The trolley must only be used on a stable, flat surface and is not designed for external use. For guidance, a standard 7' x 4' coin-operated table with a slate bed would normally weigh in the region of 300kg with the slate and legs fitted but please refer to the table manufacturer for a detailed specification.

To use the pool trolley, proceed as follows: -

1. Place the pool trolley lengthways underneath the table as near to the centre as possible with the red jack facing towards you, ensuring that the lever on the base of the jack is in the vertical position.
2. Raise the pool trolley by inserting the handle provided into the holder at the base of the jack and, using an up and down motion of the handle, raise the top platform of the pool trolley underneath the pool table until the latter has been raised **just clear** of the floor.
3. Move the pool table by **gently** pushing it in the required direction. Under no circumstances attempt to move the pool table by pushing the pool trolley itself.
4. Once the pool table has reached the desired location, the pool trolley can be lowered by inserting the hollow end of the handle over the lever at the base of the jack and moving anti-clockwise to a horizontal position.

KEEP HANDS AND FEET CLEAR OF THE POOL TROLLEY AND THE BOTTOM OF THE POOL TABLE AT ALL TIMES

FOR USE WITH POOL TABLES ONLY

**Safe Working Load 600kg
READ INSTRUCTIONS BEFORE USE**